

Specifications

CAHFT20 Sweet (Saccharin) Fit Test Kit

Kit:

- Test hood
- Sensitivity nebulizer
- Test nebulizer with atomizer
- Wire cleaner
- Box of sensitivity solution, 6 ampules
- Box of test solution, 6 ampules

Hood:

- Poly-coated
- Clear viewing window
- Surged seams
- Reusable

Sweet (saccharin):

- Glass ampules
- With pre-drilled plastic cap for easy pouring
- Plastic protection from broken glass
- One-time use
- Averages 3-5 fit tests per tube
- Contains 2.5cc of solution

Nebulizer:

- Buna-N (nitrile rubber) air bulb for easy operation
- Converts 5cc (mL) of liquid into aerosol 0.3-5.0 microns particle size
- Complete with extra jet and replaceable plastic caps
- Break-resistant polycarbonate plastic (Lexan®) that easily disassembles for washing
- Dimensions: 2 in. x 2 in. x 7 in. (5.0 cm x 5.0 cm x 17.7 cm)



This kit offers qualitative OSHA compliant fit testing for disposable and reusable dust and mist respirators. Saccharin has a sweet taste to indicate failure on the respirator fit test. New disposable glass ampules make pouring solution into nebulizers easier and reduce the chance of contamination.

Products available:

CAHFT20	Sweet (Saccharin) Fit Test Kit
CAHFT21	Sweet (Saccharin) Sensitivity Solution (6 EA/BX)
CAHFT22	Sweet (Saccharin) Test Solution (6 EA/BX)
CAHFT10	Nebulizer (1 EA)

For more information or to order, contact your Cardinal Health sales representative or visit [cardinalhealth.com/facialprotection](https://www.cardinalhealth.com/facialprotection).